

## Lotus Palm Candle Assembly

Step 1. Insert the Kevlar Strap through the wire loop by 1.5" (40mm) then coil around

Step 2. With the Kevlar Strap fold the outer end 1" (25mm) under itself to avoid fraying.

Step 3. Stitch with Kevlar thread (See also the online video).

Step 4. Place the small disc with the welded washer between and center of the leather straps.

Step 5. Thread the small nut onto the end of the rod up to where the thread stops and the rod becomes smooth.

Step 6. Connect the lotus dish to the end of the rod and then twist the rod through the slot in the leather strap and into the nut until the unit becomes tight. Additional pressure on the small disc can help to tighten. Or you can use a small spanner on the nut above the lotus dish to tighten.

