

www.homeofpoi.com

Step 1. Place two rubber rings over each end of the central coupler.



