

Thank you for your purchase of your new 11 Mode USB rechargeable LED Ball

Getting Started:

Your USB rechargeable LED ball may have some charge on arrival or none, due to customs regulations the ball must have 10% or less charge when shipping so you will need to give this a charge before use.

Charging will take around 30-40 minutes for a full charge depending on the current charge of the battery. When charging, the ball will light up indicating how much battery life is remaining. Low charge will show as red and full charge will show as green.

One charge will last around 30-40 minutes of play depending on the modes used.

Operating Instructions:

Always make sure your ball has a full charge before first use. To turn on, press and hold the button below the USB port for 4-5 full seconds and release. The ball will always turn back on to the last mode used. To turn off, press and hold the button for 4-5 full seconds and release, a faint flash will show right before turning off.

Charging:

The charge port is a standard size Micro-USB port which will only go in one way. Push the charge cable in gently until it cannot go further, then plug the other end into your USB port for charging. Once fully charged pull gently to remove the cord from the socket.

Available Modes:

- 1. Color Change through all colors
- 2. Strobe through all colors
- 3. Slow color fade through all colors
- 4. Solid Red
- 5. Solid Green
- 6. Solid Blue
- 7. Solid Yellow
- 8. Solid Indigo
- 9. Solid Purple
- 10. Solid Orange
- 11. Solid White

Happy Spinning!!