

Directions for using a Contact Claymore Large Fire Sword



Assembly:

Slide the wick over the handle and align with the push button. Depress the push button and slide in further until the push button pops into the locking hole. Pull the wick, like a sock, over the push button to hide and twist the wick to prevent it from sliding back. Reverse this process to dismantle for easy travel and storage.

Fueling:

When fueling; point vertically, blade first into container. Use scoop to pour fuel down blade, gently rotating as you go. Make sure you shake off excessively (shake it vorasciously downwards into container for a minute) to prevent fuel drippage onto hilt/hand.

Usage:

When burning; at the start hold it straight up, pointing vertically, this is your safe point. Light from the bottom of blade. Pointing it down will result in almost immediate burns (this is a common tendency in unexperienced spinners, watch out for it!). The flame will be biggest (huge) at the start. When confident in vertical safe space, take a swing along horizontal plane, returning to vertical safe space afterwards. Explore the planes you can maneuver in, and some epic poses. You must be quite skilled before attempting contact maneuvers (practice heaps unlit!), and it is recommended that they be attempted at high speed and towards the end of your burn.

One more thing: because of the breakdown design, be careful with big swings and throws! Because the weight is distributed asymetrically it could be bent with the amount of force able to be generated.

Start slowly, progress gently, respect your sword, and it will last decades.