


# HOME of POI

## Instructional guide for the Home of Poi LED Fan

When your LED fans first arrive they will have 10% or less power in them, please charge fully before first use. It is very important to please carefully read the charging instructions before starting the charge. If this not followed correctly this will void the warranty and may result in damage of the LED circuit.

**Charging:** Before plugging your LED fans into charge please make sure you have the correct adapter for the USA style plug (if required) and the power switch on the LED fan must be in the off position as shown below. This power button is separate from the remote power button. (Note your LED Fan will have a silicone cap over the ends, the photo below is to correctly show how the button should be positioned for on and off)



While charging the LED on the charger will show as red and once fully charged will show green, You can then disconnect the charger and turn the main power switch into the on position.

**Storage:** When storing your LED fans ensure the main power button on each unit is in the off position as leaving on will result in the battery draining over time.

Please read carefully your remote instructions below.

